Manual Release Operation

Manual release handle in closed position.

Open lock cover and insert key. Turn key ¼ turn counter clockwise to unlock.

Pull manual release handle down to enable manual release